


ATV250-EC PARTS CATALOG

REF.NO PART NO.


DESCRIPTION

名 称

数量 1




1-1	11102010-000FG-000000	PNEUMATIC CAM SHAFT ASSY	配气凸轮轴	1
1-2			传动销	1
1-3			轴承6005-RS	1
1-4			轴承6202-Z	1
1-5	11004010-000FG-000000	TIMING SPROCKET	正时链轮	1
1-6	91000000-10025-578786	BOLT M10×1.25×25	螺栓 M10×1.25×25	1
1-7	11004020-000FG-000000	WASHER	垫圈	1
1-8	11300000-000FG-000000	TIMING CHAIN	正时链条	1
1-9	11400000-000FG-000000	LOWER GUIDE PLATE	下导向板	1
1-10	11500000-000FG-000000	UPPER GUIDE PLATE ASSY	上导向板总成	1
1-11	11200000-000FG-000000	CHAIN TENSIONER	链条张紧器	1
1-12	11008010-000FG-000000	SHIM OF TENSIONER	张紧器垫片	1
1-13	91000000-06025-095026	BOLT 95026-06025	螺栓	2
1-14	91000000-06014-027694	BOLT 95026-06014	螺栓	2
1-15	11103030-000FG-000000	AIR VALVE	气门	1
1-16	11104010-000FG-000000	VALVE SPRING SEAT	气门弹簧座	2
1-17	11107010-000FG-000000	VALVE SPRING	气门弹簧	2




1-18	11120000-000FG-000000	VALVE STEM OIL SEAL	气门杆油封	2
1-19	11103010-000FG-000000	VALVE SPRIG COVER	气门弹簧盖	2
1-20	11103020-000FG-000000	VALVE LOCK CLIP	气门锁夹	4
1-21	11106010-000FG-000000	O-RING	O形圈	1
1-22	11100020-000FG-000000	ROCKER ARM SHAFT 2	摇臂轴2	1
1-23	11100010-000FG-000000	ROCKER ARM SHAFT 1	摇臂轴1	1
1-24	11130000-000FG-000000	VALVE ROCKER ARM ASSY	气门摇臂组件	2

FIG. 2 cylinder cap




2-1	11110000-000FG-000000	CYLINDER CAP UNIT	气缸盖组合	1
2-2	91000000-06010-095026	BOLT 95026-06010	螺栓95026-06010	1
2-3	11004050-000FG-000000	WASHER	垫圈	1
2-4	11006040-000FG-000000	DAMPER	减震块	8
2-5	11010000-000FG-000000	CYLINDER CAP SHIM UNIT	气缸盖垫片组合	1
2-6	91000000-14016-099510	ALIGNMENT PIN 99510-14016	定位销 99510-14016	2
2-7	11000020-000FG-000000	ALIGNMENT PIN	定位销	1
2-8	11006030-000FG-000000	OIL SEAL	油封	1
2-9	11010000-00ZA1-000000	CAP NUT	盖形螺母	4
2-10	11004040-00ZA1-000000	WASHER	垫圈	4
2-11	91000000-08045-007085	SCREW M8×45-10.9	螺钉M8×45-10.9	2
2-12	91000000-08000-084885	WASHER 8	垫圈8	2
2-13	11030000-000FG-000000	SPROCKET CHAMBER COVER UNIT	链轮室盖组合	1
2-14	11020000-000FG-000000	OIL BAFFLE UNIT	挡油盘组合	1
2-15	11006060-000FG-000000	AIR DRAIN	通气管	1
2-16	11007010-000FG-000000	HOOP	卡箍	1
2-17	11006020-000FG-000000	O-RING	O形圈	1




2-18	91000000-06012-098512	SCREW 98512-06012	螺钉98512-06012	2
2-19	11006050-000FG-000000	O-RING	O形圈	1
2-20	91000000-06020-098512	SCREW 98512-06020	螺钉98512-06020	2
2-21	11002020-000FG-000000	UPPER VALVE COVER	上气门盖	1
2-22	11002010-000FG-000000	LOWER VALVE COVER	下气门盖	1
2-23	11006010-000FG-000000	O-RING	O形圈	2
2-24	91000000-06018-007085	SCREW M6×18-10.9	螺钉 M6×18-10.9	5
2-25	11104030-06020-098512	PRESSURE PLATE	压板	1
2-26	91000000-06012-578386	BOLT M6×12	螺栓 M6×12	2
2-27	11104020-06020-098512	STOP PLATE	止动板	1
2-28	11110001-06020-098512	SPARK PLUG	火花塞	1

FIG. 3 CRANK CONNECTING ROD MECHANISM




3-1	12100000-000FG-000000	CRANK CONNECTING ROD ASSY	曲轴连杆总成	1
3-2	91000000-03013-109979	WOODRUFF KEY 3×5×13	半圆键 3×5×13	1
3-3	12202010-000FG-000000	PISTON	活塞	1
3-4	12200010-000FG-000000	PISTON RING ASSY	活塞环组件	1
3-5	12000010-000FG-000000	PISTON PIN	活塞销	1
3-6	12007010-000FG-000000	CIRCLIP	挡圈	2
3-7	12003030-000FG-000000	BLANCE SHAFT DRIVING GEAR	平衡轴驱动齿轮	1
3-8	13003010-000FG-000000	BLANCE SHAFT ASSY	平衡轴	1
3-9			平衡轴齿轮	1
3-10			轴承6304	2
3-11			平键	1
3-12			锁紧垫圈	1
3-13			螺母	1
3-14	12000020-000FG-000000	WOODRUFF KEY	半圆键	1
3-15	91000000-06306-027694	BEARING 6306/c4	轴承6306/c4	1
3-16	91000000-26000-089496	CIRCLIP 26	挡圈26	1
3-17	91000000-06018-081985	SCREW M6×18	螺钉M6×18	3
3-18	12004010-000FG-000000	PRESSURE PLATE	压板	1
3-19	91000000-06203-027694	BEARING 6203	轴承6203	1
3-20	12020000-000FG-000000	OIL SEAR	油封	1




3-22	12008010-000FG-000000	CYLINDER SHIM	汽缸体垫片	1
3-23	12006010-000FG-000000	O-RING	O型圈	1
3-24	91000000-14016-099530	ALIGNMENT PIN 99530-14016	定位销99530-14016	2
3-25	91000000-06025-007085	SCREW M6×25-10.9	螺钉M6×25-10.9	2


FIG. 4 CRANKCASE BODY PART



4-1	13008010-000FG-000000	LEFT CRANKCASE COVER GASKET	左曲轴箱盖密封垫	1
4-2	91000000-12016-99530	PIN 99530-12016	销99530-12016	8
4-3	13002010-000FG-000000	LEFT CRANKCASE COVER	左曲轴箱盖	1




4-4	91000000-06080-098512	SCREW 98512-06080	螺钉98512-06080	1
4-5	91000000-06030-098512	SCREW 98512-06030	螺钉98512-06030	1
4-6	91000000-06025-098512	SCREW 98512-06025	螺钉98512-06025	5
4-7	91000000-06050-098512	SCREW 98512-06050	螺钉 98512-06050	1
4-8	91000000-06060-098512	SCREW 98512-06060	螺钉98512-06060	1
4-9	13008020-000FG-000000	RIGHT CONNECTING CASE GASKET	右连接箱密封垫	1
4-10	91000000-06040-098512	SCREW 98512-06040	螺钉 98512-06040	7
4-11	13400000-000FG-000000	RIGHT CRANKCASE COVER	右曲轴箱盖	1
4-12	13002020-000FG-000000	RIGHT CONNECTING CASE	右连接盖	1
4-13	13008030-000FG-000000	RIGHT CRANKCASE COVE GASKET	右曲轴箱盖密封垫	1
4-14	91000000-06070-098512	SCREW 98512-06070	螺钉 98512-06070	5
4-15	13010000-000FG-000000	OIL DIPSTICK	油尺	1
4-16	13006010-00ZA1-000000	O-RING	O形圈	1
4-17	13200000-000FG-000000	RIGHT CRANKCASE ASSY	右曲轴箱总成	1
4-18	13100000-000FG-000000	LEFT CRANKCASE ASSY	左同轴箱总成	1
4-19	13002030-000FG-000000	RIGHT DRIVING COVER	后传动盖	7
4-20	91000000-06030-098512	SCREW 98512-06070	螺钉 98512-06070	2
4-21	13000010-000FG-000000	ALIGNMENT PIN 010×14	定位销 010×14	5
4-22	91000000-06035-007085	SCREW 98512-06030	螺钉98512-06030	2
4-23	91000000-06060-099512	PIN 98512-06060	销98512-06060	1
4-24	91000000-06060-098512	SCREW 98512-06060	螺钉98512-06060	1
4-25	91000000-06085-098512	SCREW 98512-06085	螺钉98512-06085	1




4-26	91000000-06160-007085	SCREW M6×160-10.9	螺钉M6×160-10.9	1
4-27	91000000-06075-098512	SCREW 98512-06075	螺钉98512-06075	1
4-28	13020000-000FG-000000	SPRUE	堵头	1
4-29	91000000-28000-089386	CIRCLIP 28	挡圈28	1
4-30	13008510-000FG-000000	DOUBLE-HEAD SCREW	双头螺栓	4

FIG. 5 CLUTCH




5-1	14110000-000FG-000000	MAIN CLUTCH ASSY	主离合器总成	1
5-2	14004020-000FG-000000	WASHER	垫圈	1
5-3	14004010-000FG-000000	LOCKING WASHER	锁紧垫圈	1
5-4	14008540-000FG-000000	NUT	螺母	1
5-5	14210000-000FG-000000	CLUTCH ASSY	离合器组件	1
5-5-1			离合器主动摩擦盘	5
5-5-2			离合器从动摩擦盘	4
5-6	91000000-06000-027694	BEARING 6000	轴承6000	1
5-7	14003010-000FG-000000	CLUTCH POST ROD	离合器顶杆	1
5-8	14004030-000FG-000000	LOCKING WASHER	锁紧垫圈	1
5-9	12008510-000FG-000000	NUT	螺母	1
5-10	14000010-000FG-000000	GUIDE ROD	导向杆	1
5-11	14004040-000FG-000000	LOWER CAM PLATE	下凸轮板	1
5-12	14100000-000FG-000000	STEEL BALL BRACKET UNIT	钢球架组合	1
5-13	14020000-000FG-000000	UPPER CAM PLATE UNIT	上凸轮板组合	1
5-14	14030000-000FG-000000	PERATION ROCKER ARM UNIT	操纵摇臂组合	1
5-15	14007010-000FG-000000	COMPRESSION SPRING	压簧	1
5-16	14008520-000FG-000000	CONNECTING PIN 1.2×14	连接销1.2×14	1
5-17	14000020-000FG-000000	SUPPORT SEAT	支承座	1




5-18	91000000-08000-097851	WASHER 8	垫圈8	1
5-19	91000000-01014-009186	COTTER PIN	开口销	1
5-20	14008530-000FG-000000	ADJUSTING SCRWE	调节螺钉	1
5-21	14006010-000FG-000000	O-RING	O形圈	1
5-22	91000000-08000-000848	WASHER 8	垫圈8	1
5-23	14008510-000FG-000000	LOCKING NUT	锁紧螺母	1

FIG. 6 gear shift OPERATION device



6-1	14020000-00ZA1-000000	OIL SEAL	油封	1
6-2	15300000-000FG-000000	SHIFT ASSY	换档总成	1
6-2-1			换档杠杆	1
6-2-2			换档轴	1
6-2-3			扭簧销	1
6-2-4			换档扭簧	1
6-3	15004020-000FG-000000	WASHER	垫圈	2
6-4	15600000-000FG-000000	LIMIT LEVER ASSY	限位杠杆总成	1
6-5	15007020-000FG-000000	LIMIT LEVER SPRING	限位扭簧	1
6-6	15700000-000FG-000000	SHIFT PEDAL ASSY	换挡踏板总成	1


FIG. 7 gear shift OPERATION device




7-1	15910000-000FG-000000	LEVER ASSY
7-2	15070000-000FG-000000	WASHER
7-3	15060000-000FG-000000	WASHER
7-4	15008520-000FG-000000	SCREW
7-5	91000000-06020-007085	SCREW M6×20-10.9

手柄组件	1
垫圈	4
垫圈	2
螺钉	1
螺钉M6×20-10.9	2

FIG. 8 output device




8-1	91000000-08025-081985	SCREW M8×25	螺钉M8×25	3
8-2	15004010-000FG-000000	PRESSURE PLATE	压板	1
8-3	91000000-06304-027694	BEARING 6304	轴承6304	1
8-4	15004090-000FG-000000	WASHER	垫圈	1
8-5	15003040-000FG-000000	FINN GEAR	输出齿轮	1
8-6	15810000-000FG-000000	FORWARD GEAR UNIT	正档齿轮组合	1
8-7	15833010-000FG-000000	REVERSE GEAR	倒档齿轮	1
8-8	15008510-000FG-000000	NUT	螺母	1
8-9	91000000-06006-027694	BEARING 6006	轴承6006	1
8-10	15804070-000FG-000000	WASHER	垫圈	1
8-11	15803020-000FG-000000	CONNECTING PAW	连接爪	1
8-12	15804040-000FG-000000	WASHER	垫圈	1
8-13	15840000-000FG-000000	BEARING	轴承	1
8-14	15838510-000FG-000000	NUT SLEEVE	螺套	1
8-15	15838520-000FG-000000	SHAPED LEFT HARDED	异形左旋螺母	1
8-16	15803010-000FG-000000	OUTPUT SHAFT	输出轴	1
8-17	15804040-000FG-000000	WASHER	垫圈	1
8-18	15850000-000FG-000000	BEARING	轴承	1
8-19	15808510-000FG-000000	INTERNAL HEXAGONAL NUT	内六方螺套	1
8-20	15803030-000FG-000000	CROSS JOINT ASSY.	万向节组件	1




8-20-1			前接头	1
8-20-2			后接头	1
8-20-3			传动叉	1
8-20-4			滚针轴承	4
8-20-5			卡圈	4
8-21	15832010-000FG-000000	REAR COVER	后盖	4
8-22	15836010-000FG-000000	O-RING	O形圈	1
8-23	91000000-08025-578786	BOLT M8×25	螺栓M8×25	1
8-24	15003050-000FG-000000	REVERSE SHIFT FORK	倒档拨叉	1
8-25	15007030-000FG-000000	COMPRESSION SPRING	压簧	1
8-26	91000000-06000-030889	STEEL BALL 6.35G100b	钢球 6.35G100b	1
8-27	15000060-000FG-000000	REVERSE SHIFT FORK SHAFT	倒档拨叉轴	1
8-28	15040000-000FG-000000	REVERSE CONTROL LEVER UNIT	倒档控制杆组合	1
8-29	15000070-000FG-000000	REVERS CONTROL SHAFT	倒档操纵轴	1
8-30	91000000-14000-089486	CIRCLIP 14	挡圈14	1
8-31	15004030-000FG-000000	OPERATION PLATE	操纵板	1
8-32	15004040-000FG-000000	LEVER PLATE	杠杆板	1
8-33	91000000-06016-578986	BOLT M6×16	螺栓M6×16	1
8-34	15050000-000FG-000000	OIL SEAL	油封	1
8-35	15006010-000FG-000000	O-RING	O形圈	1
8-36			垫圈	1
8-37			螺母	1

FIG. 9 change speed gear device




9-1	15110000-000FG-000000	SPINDLE ASSY	主轴组件	1
9-2	91000000-06204-027694	BEARING 6204	轴承6204	1
9-3	15010000-000FG-000000	OIL SEAL	油封	1
9-4	91000000-06202-027694	BEARING 6202	轴承6202	2
9-5	15210000-000FG-000000	DRIVE AXLE ASSY	副轴组件	1

FIG. 10 shift cam, shift fork device




10-1	15400000-000FG-000000	SHIFT CAM AXLE ASSY	换档凸轮轴组件	1
10-1-1			换档凸轮	1
10-1-2			滚针轴承	1
10-1-3			星型轮	1
10-1-4			螺钉6*35	1
10-2	15003020-000FG-000000	SHIFT FORK 2	拨叉2	1
10-3	15003030-000FG-000000	SHIFT FORK 3	拨叉3	1
10-4	15003010-000FG-000000	SHIFT FORK 1	拨叉1	1
10-5	15000010-000FG-000000	LONG SHIFT FORK AXLE	长拨叉轴	1
10-6	15000020-000FG-000000	SHORT SHIFT FORK AXLE	短拨叉轴	1

FIG. 11 HAND STARTING




11-1	18700000-000FG-000000	HAND STARTING ASSY	手操起动组件	1
11-2	91000000-06020-098512	SCREW 98512-06020	螺钉98512-06020	6
11-3	18070000-000FG-000000	BOSS ONE-WAY UNIT	起动棘轮组合	1
11-4	18006010-000FG-000000	O-RING	O形圈	1
11-5	18004040-000FG-000000	WASHER	垫圈	1
11-6	91000000-10000-009387	WASHER	垫圈	1
11-7	91000000-10125-578585	BOLT M10×125×40	螺栓M10×125×40	1
11-8	18060000-000FG-000000	OIL SEAL	油封	1
11-9	15840000-000FG-000000	BEARING	轴承	1
11-10	18004030-000FG-000000	PRESSING PLATE	压板	1
11-11	91000000-05016-098512	SCREW M5×16	螺钉M5×16	3

FIG. 12 LUBRICATIO SYSTEM




12-1	16100000-000FG-000000	ENGINE OIL PUMP	机油泵	1
12-2			螺钉6*30	3
12-3	16008010-000FG-000000	OIL PUMP PAD	油泵垫片	1
12-4	16200000-000FG-000000	ENGINE OIL COARSE STRAINER	机油粗滤器	1
12-5	16007010-000FG-000000	COMPRESSING SPRING	压簧	1
12-6	16002010-000FG-000000	OIL DRAIN PLUG SCREW	放油螺塞	1
12-7	16006010-000FG-000000	O-RING	O形圈	1
12-8	16300000-000FG-000000	ENGINE OIL FINE STRAINER	机油精滤器	1
12-9	16002020-000FG-000000	ENGINE OIL FINE STRAINER COVER	机油精滤器盖	1
12-10	16006020-000FG-000000	O-RING	O形圈	1
12-11	91000000-06020-007085	SCREW M6×20-10.9	螺钉M6×20-10.9	2
12-12	91000000-06115-007085	SCREW M6×115-10.9	螺钉M6×115-10.9	1

FIG. 13electric starter




13-1	18007510-000FG-000000	DUPLUX GO GEAR	双连过轮	1
13-2	18000010-000FG-000000	GO GEAR AXLE	过轮轴	1
13-3	18004010-000FG-000000	WASHER	垫圈	2
13-4	91000000-12000-894186	CIRCLIP 12	挡圈12	2
13-5	18600000-000FG-000000	GEAR ASSY OF ELECTRIC STARTER	电起动齿轮组件	1
13-6	18004020-000FG-000000	WASHER	垫圈	1
13-7	18300000-000FG-000000	CLUTCH OF ELECTRIC STARTER ASSY	电起动离合器组件	1
13-8	18500000-000FG-000000	STARTING MOTOR	起动电机	1
13-9	18004050-000FG-000000	CONNECTING BOARD OF STARTING MOTOR	起动电机连接板	1
13-10	91000000-06115-097602	SCREW 97602-06115	螺钉97602-6115	2
13-11	18400000-000FG-000000	MAGNETO	磁电机	1
13-11-1			定子	1
13-11-2			转子	1
13-12	91000000-06215-097602	SCREW 97602-06215	螺钉97602-06215	3
13-13			螺钉8*16	3

FIG. 14INTAKE SYSTEM




14-1	20401010-250ST-000000	CARBURETOR SEAT	化油器座	1
14-2	92401010-06016-578786	SCREW M6×16	螺钉M6×16	2
14-3	92401020-06016-578786	SCREW M6×16-10.9	螺钉M6×16-10.9	2
14-4	20102000-250ST-000000	AIR FILTER ASSY	空滤器组件	1
14-4-1	20102010-250ST-000000	FILTER CORE UNIT	滤芯组合	1
14-5	20401000-250ST-000000	CARBURETOR	化油器	1


FIG. 15 intake system




15-1			消声器总成	1
15-1-1	117200	EXHAUST PIPE UNIT 1	排气管	1
15-1-2	117002	THERMAL PLATE UNIT OF EXHAUT PIPE	防烫板	1
15-1-3	sB0610	BOLT M6×10	螺栓M6×10	2
15-1-4	117100	SILENCER ASSY	消声器体	1
15-1-5	117073	EXHAUST PIPE WASHER	消声器石棉垫	1
15-1-6	D00620-18	SCREW M6×20-10.9	螺钉M6×20-10.9	2
15-1-7	117075	SEAL RING OF EXHAUST PIPE	消声器中段密封圈	1
15-1-8	114200	THROTTLE SWITCH	进气负压开关	1
15-2	SB0820	BOT M8×20	螺栓M8×20	2
15-3	Q30800	WASHER 8	垫圈8	2
15-4	Q00800	WASHER 8	垫圈8	2
15-5	D00616	SCREW M6×16	螺钉M6×16	2
15-6	114100	THROTTLE VALVE ASSY	节气阀部件	1



16-1	501100	FRAME	车架	1
16-2	501002	CONNECTIO PLATE COMBINATION ON ENGINE	发动机上左连接板	1
16-3	sB0816	BOLT M8×16	螺栓M8×16	2
16-4	sB0860	BOLT M8×55	螺栓M8×55	1
16-5	sB0890	BOLT M8×65	螺栓M8×65	4
16-6	sB08A5	BOLT M8×105	螺栓M8×105	2
16-7	mc0800	NUT M8	螺母M8	5
16-8	912210	BUSH, SOLID	衬套	2
16-9	50207030-250ST-000000	NIPPLE, GREASE	加油嘴	1
16-10	506100	REAR SHOCK ABSORBER	后减震器	1
16-11	s51275	BOLT M12×75	螺栓M12×75	1
16-12	mc1200	NUT M12	螺母M12	1
16-13	912103	REAR SHOCK ABSORBER PIN	后减震轴	1
16-14	q21200	WASHER 12	垫圈12	1
16-15	X03B30	SPLIT PIN 3.2×30	开口销 3.2×30	1
16-16	506171	REAR SHOCK ABSORING RUBBER PAD UNIT	后减震胶垫	2
16-17			风扇支架	1
16-18			风扇	2



17-1	525200	FRONT LEFT WHEEL FORK WELD	前左摇臂组合	1
17-1-1			前左摇臂衬套	4
17-2	525300	FRONT RIGHT WHEEL FORK WELD	前右摇臂组合	1
17-3	sB1070	BOLT M10×70	螺栓M10×70	4
17-4	mc1000	NUT M10	螺母M10	4
17-5	505100	FRONT SHOCK ABSORBER	前减震器	2
17-6	505130	FRONT SHOCK ABSORBER NUT	前减震螺母	2
17-7	a23200	CIRCLIP 32	挡圈32	4
17-8	525400	STEERING KNUCKLE ASSY,R	左前转向支座组合	1
17-9	525500	STEERING KNUCKLE ASSY,L	右前转向支座组合	1
17-10	md1200-6	NUT M12×1.25	螺母M12×1.25	2
17-11	x03b30	COTTER PIN 3.2×30	开口销3.2×30	2
17-12	s51250	BOLT M12×50	螺栓M12×50	4
17-13	Mc1200	NUT M12	螺母M12	4
17-14	d00812	BOLT M8×12	螺钉 M8×12	4
17-15	409000	FRONT HPLRAULIC BRAKE	前碟刹总成 (含碟刹盘)	1
17-15-1			前碟刹上泵(含油杯、油管)	1
17-15-2			前碟刹下泵	2
17-15-3			前碟刹油管	3
17-15-4			前碟刹三通	1
17-15-5			前碟刹摩擦片	2
17-16	sB0616	SCREW M6×16	螺栓M6×16	1




17-17 x02e20
 17-18 q10600
 17-19 x40618


COTTER PIN $\Phi 2.5 \times 20$
 WASHER $\Phi 6$
 AXLE PIN $\Phi 6 \times 18$

开口销 $\Phi 2.5 \times 20$
 垫圈 $\Phi 6$
 轴销 $\Phi 6 \times 18$


1
 1
 1




18-1	401100	FRONT RIM	前轮毂	2
18-2	402001	FRONT TIRE	前轮外胎	2
18-3	402102	AIR CHAIN MOUTH WITHOUT TUBE	前轮气门芯	2
18-4	409074	FRONT PEDESTAL	前碟刹盘座	2
18-5	401075	CONNECTING NUT OF FRONT AND REAR WHEELS	前后轮联接螺母	8
18-6	Q21400-21	WASHER 14-140HV	垫圈14-140HV	2
18-7	M11400	NUT M14	螺母M14	2
18-8	X03B26	COTTER PIN 3.2×26	开口销3.2×26	2
18-9	401107	DUST-PROOF COVER OF FRONT AND REAR WHEELS	前轮防尘盖	2
18-10	409001	BRAKE DISC	碟刹盘	2
18-11	T12210-008016	BOLT M8×16	螺栓 M8×16	8




19-1	604100-0150010	STEERING UPRIGHT COLUMN WELD	转向立柱焊接	1
19-2	604201-0150010	UPPER GRIPPER BLOCK OF STEERING BAR	方向把上夹持器	2
19-3	604202-0150010	LOWE GRIP SLIPER OF STEERING BAR	方向把下夹持座	1
19-4	sa0850	BOLT M8×50	螺栓M8×50	2
19-5	s90816	BOLT M8×16	螺栓M8×16	2
19-6	604216-0150010	GRIP SLIPPER OF STEERING UPLIGHT COLUMN	转向立柱夹持座	2
19-7	T51320	SEALING RING Φ32	密封圈 Φ32	2
19-8	604215-0150010	WIRE CLIP UNIT	线夹组合	1
19-9	s50860	BOLT	螺栓M8×60	4
19-10	604217	LOCKING SHIM	锁紧垫片	1
19-11	604218	BUSHING	衬套	2
19-12	q41000	WASHER 10	垫圈10	1
19-13	ma1000	NUT M10	螺母M10	1
19-14	x02e24	COTTER PIN	开口销2.5×24	1
19-15	605000-0150010	STEERING TENSION ROD ASSY	转向拉杆总成	2
19-15-1			转向拉杆本体	2
19-15-2		JOINT COMP(IN)	转向拉杆球绞组合 (内)	2
19-15-3		JOING COMP(OUT)	转向拉杆球绞组合 (外)	2
19-16			方向锁	1



20-1	601001	STEERIG BAR TUBE	手把管	1
20-2	602100	LEFT HANDLE BAR	手把胶	2
20-3	607000	THROTTLE CABLE	油门拉索	1
20-4	610000	REAR BRAKE CABLE	后制动拉索	1
20-5	602200	THROTTLE LEVER ASSY	加油器总成	1
20-6	902100	LEFT REARVIEN MIRROR	左后视镜	1
20-7	902200	RIGHT REARVIEN MIRROR	右后视镜	1
20-8	902171	SLECVE, REARVIEN MITTOR	后视镜胶套	2
20-9	813400	INSTRUMENT COVER	仪表壳	1
20-10	Q10500	WASHER $\Phi 5$	平垫 $\Phi 5$	1
20-11	342000	URGENT SWITCH	应急开关	1
20-12	G00325	SCREW 3×25	螺钉 3×25	4
20-13	323000	INSTRUMENT	仪表	1
20-14	505300	FRAMT, HEADLIGHT	前照灯支架	1




20-15	SA0816	BOLT M8×16	螺栓M8×16	2
20-16	314000	HEADLIGHT ASSY	前照灯	1
20-16-1			前照灯灯泡	1
20-17	812100	SHELL, HEADLIGHT	前照灯壳	1
20-18	D20512	SCREW M5×12	螺钉M5×12	1
20-19	M10500	NUT M5	螺母 M5	1
20-20	D20440	ADJUSTING BOLT M4×40	调整螺栓 M4×40	1
20-21	M10400	NUT M4	螺母 M4	2
20-22	Q10400	WASHER Φ4	平垫 Φ4	1
20-23	314012	SPRING Φ4×30	前照灯弹簧 Φ4×30	1




21-1	324201	LEFT HANDLE BAR ASSY
21-2	324216	RIGHT LEVER ASSY
21-2-1	40501000-250ST-000000	CLUTCH SWITCH


左闸把开关体	1
后制动手柄	1
制动信号开关	1




22-1	505100-0150010	REAR WHEEL FORK UNIT	后轮叉组合	1
22-1-1	505212-0150010	REAR ARM CONNECTION BOLT(LEFT)	后臂联接螺栓(左)	1
22-1-2	505213-0150010	REAR ARM CONNECTION BOLT(RIGHT)	后臂联接螺栓(右)	1
22-1-3	505214-0150010	REAR ARM NUT M22(RIGHT)	后臂螺母M22 (右)	1
22-1-4	505215-0150010	REAR ARM DUST-PROOF COVER	后臂轴防尘盖	2
22-1-5			平叉轴衬套	2
22-1-6			后臂联接轴承30203	2
22-1-7			后臂联接油封25*40*7	2
22-2	505300-0150010	REAR WHEEL AXLE SLEEVE	后轮轴套筒	1
22-2-1	505220-0150010	OIL SEAL	油封	1
22-2-2	c06206-2rs	BEARING 6206-2RS	轴承6206-2RS	1
22-3	s91225	BOLT M12×25	螺栓 M12×25	4
22-4	mc1200	NUT M12	螺母 M12	4
22-5	505217-0150010	DRIVING AXLE CLAMP UNIT(FRONT)	传动轴夹箍组合(前)	1
22-6	505216-0150010	TRANSMISSION CASE PROTECTIVE COVER	传动箱保护罩	1
22-7	505219-0150010	BUFLEG PAD OF LOWER COVER OF GEAR BOX	齿轮箱下盖缓冲垫	3
22-8	s90812	BOLT M8×12	螺栓M8×12	2
22-9	s71025-6	BOLT M10×1.25×25	螺栓M10×1.25×25	4
22-10	505202-0150010	DUST COVER	防尘罩	1
22-11			拖车球	1




23-1	205700-0150010	REAR DRIVING GEAR ASSY	驱动齿轮	1
23-1-1	205701-0150010	DRIVING GEAR BOX BODY	驱动齿轮箱体	1
23-1-2	205702-0150010	AIR-DRAINING JOINT	驱动齿轮箱盖	2
23-1-3	205761-0150010	O-RING 85×3.55G	O形圈 85×3.55G	1
23-1-4	m21000-6	NUT M10×1.25	螺母 M10×1.25	4
23-1-5			油封 53.1X 8.3	1
23-1-6			O形圈58X2	1
23-1-7			丝圈	1
23-1-8			轴套	1
23-1-9			轴承6305	1
23-1-10			调整垫片	1
23-1-11			角齿	1
23-1-12			滚针轴承	1
23-1-13			放油螺丝	1
23-1-14			油封63.1X8.5	1
23-1-15			进油螺丝	1




23-1-16			油封68.1X9	1
23-1-17			滚针轴承556720	1
23-1-18			含油垫片	1
23-1-19			盆齿	1
23-1-20			调整垫片	1
23-1-21			轴承16013	1
23-1-22			油封 85X8.5	1
23-1-23			O型圈150X3.10	1
23-2	205102-0150010	DRIVING AXLE	传动轴	1
23-3	a22100	CIRCLIP 21	挡圈21	1
23-4	205762-0150010	GEAR BOX AIR -DRAIN	齿轮箱通气管	1
23-5	205763-0150010	BRAKE AIR-DRAIN CLAMP	制动器通气管夹子	1
23-6	204078	MAGNETIC BLOCK	磁块	1
23-7	204075	SPEED SENSOR	速度传感器	1
23-8	SB0625	BOLT M6×25	螺栓 M6×25	3




24-1	402100-0150010	REAR RIM UNIT	后轮辋组合	2
24-2	40400-0150010	REAR TIRD	后轮胎	2
24-3	512108-0150010	REAR WHEEL CONNECTING PLATE ASSY	后轮联接板组件	1
24-4	405000-0150010	REAR BRAKE ASSY	后制动组合	1
24-4-1			后制动鼓	1
24-4-2			制动蹄块	1
24-4-3			弹簧	1
24-4-4			制动器油封	1
24-5	512102-0150010	REAR WHEEL AXLE	后轮轴	1
24-6	402012-0150010	WASHER 16	垫圈 16	2
24-7	402011-0150010	REAR WHEEL AXLE NUT M16	后轮轴螺母 M16	2
24-8	x03b30	COTTER PIN 3.2×30	开口销 3.2×30	2
24-9	931102-0150010	AIR FLOW PIPE OF REAR BRAKE	后制动器通气管	1
24-10			后轮轴防尘垫圈	1
24-11			O型密封圈	1




25-1	510100	BRACKET WELD	主搁脚	2
25-2	SB1022	BOLT M10×22	螺栓M10×22	4
25-3	523100	FIXED MOUNT, LEFT FOOT WELL	左搁脚踏板本体	1
25-4	SB0816	BOLT M8×16	螺栓M8×16	8
25-5	M80800	NUT M8	螺母M8	4
25-6	523200	STAND WELD (RIGHT)	右搁脚踏板本体	1
25-7	408200	REAR BRAKE PEDAL ASSY	后制动踏板	1
25-8	408100	REAR BRAKE TENSION ROD ASSY	后制动拉杆	1
25-9	526001	REAR BRAKE SWITCH	后制动开关	1
25-10	408272	SPRING , REAR BRAKE SWITCH	后制动开关拉簧	1
25-11	522100	LEFT BRACKET	左搁脚	1
25-12	522200	RIGHT BRACKET	右搁脚	1




26-1	801100-0150010	FUEL TANK BODY	油箱体	1
26-1-1			油箱盖	1
26-1-2	801189-0150010	HOSE 5270-05×15 (500mm)	胶管5270-05×15长(500mm)	1
26-1-3			油开关	1
26-1-4	H10616	Screw M6×16	组合螺钉 M6×16	2
26-1-5	801081-0150010	RUBBER BUSH OF FUEL TANK	油箱胶套2	2
26-1-6	801183-0150010	RUBBER BUSH OF FUEL TANK	油箱胶套	2
26-2	801082-0150010	INSTLLING BUSHING OF UPPE RFUEL TANK LOVER	油箱上盖安装衬套	2
26-3	s90640	BOLT	螺栓M6×40	2
26-4	801184-0150010	INSTALLING BUSHING OF FUEL TANK	油箱安装衬套	2
26-5	s90635	BOLT	螺栓M6×35	2
26-6	801186-0150010	FUEL INTAKE PIPE	进油管	1
26-7	801188-0150010	STEEL WIRE CLASP	钢丝夹	2
26-8	931301-0150010	SUPPORTING DAMPER OF AIRFLOWE PIPE	通气管支撑垫	1
26-9			油滤器	1



27-1	802100-0150010	FROTN FEDNER	前挡泥板	1
27-2	802286-0150010	LEFT FRONT FENDER FLAP	左前挡泥下护板	1
27-3	802202-0150010	RIGHT FRONT FENDER FLAP	右前挡泥下护板	1
27-4	802301-0150010	R. PROTECTING PLATE	前挡泥右护板	1
27-5	802302-0150010	L. PROTECTING PLATE	前挡泥左护板	1
27-6			右油箱护板	1
27-7			左油箱护板	1
27-8	806200-0150010	HEADLIGHT COVER	前大灯罩	1
27-9	803400-0150010	UPPER COVER OF FUEL TANK	油箱上盖	1
27-10	809101-0150010	PAN HEAD SCREW	盘头螺钉	8
27-11	809102-0150010	PLASTIC EXPANSION SCREW ASSY	塑料膨胀钉组合	40
27-12	809201-0150010	FRONT FENDER SUPPORTING ROD	前挡泥板撑杆	1
27-13	s90816	BOLT M8×16	螺栓M8×16	2
27-14	314100-0150010	HEADLIGHT ASSY	前照灯组件	2
27-14-1	314110-0150010	BULB 12V30W	灯泡 12V30W	2
27-15	d20512	SCREW 5×12	螺钉M5×12	6



28-1	807100	REAR FENDER	后挡泥板	1
28-2	807054	LEFT PEDAL	后挡泥板左前护板	1
28-3	807055	RIGH PEDAL	后挡泥板右前护板	1
28-4	807052	L. PROTECTING PLATE	后挡泥左护板	1
28-5	807053	R. PROTECTING PLATE	后挡泥右护板	1
28-6	807051	R. RR. PROTECTING PLATE	后挡泥右后护板	1
28-7	807050	L. RR. PROTECTING PLATE	后挡泥左后护板	1
28-8	520100	TOOL KIT UNIT	工具盒	1
28-9	520078	TOOL KIT CATCH	工具盒扣	2
28-10	303273	SHOCK PROOF PAD	电瓶胶垫	5
28-11	t12000-006016	PAN HEAD SCREW M6×16	盘头螺钉 M6×16	10
28-12	m80600	NUT M6	螺母M6	10




29-1 701000


SEAT

座垫


1




30-1	519100	BUMPER	保险杠	1
30-2	SB0816	BOLT M8×16	螺栓M8×16	16
30-3	M80800	NUT M8	螺母 M8	16
30-4	704000	FRONT LUGGAGE CARRIER	前载物架	1
30-5	702100	REAR LUGGAGE CARRIER	后载物架	1
30-6	806092	FRONT SAFEGUARD	前防护板	1
30-7	316000	FRONT TURN LIGHT, L	左前转向灯	4
30-8	M81000	NUT M10	螺母 M10	4
30-9	M10500	NUT M15	螺母 M5	2
30-10	310000	SIDE REFLECTOR	侧光片	2
30-11	316072	CABLE CLIP	转向灯线卡	14
30-12	317000	FRONT TURN LIGHT, R	右前转向灯	1
30-13	318000	REAR TURN LIGHT, L	左后转向灯	1
30-14	319000	REAR TURN LIGHT, R	右后转向灯	1
30-15	316006	BULB, TURN LIGHT 12V/10W	转向灯泡 12V/10W	4
30-16			绞盘	1
30-17			螺栓	



31-1	520200	TOOL BOX COVER	工具盒盖	1
31-2	M80600	NUT M6	螺母M6	2
31-3	Q20600	WASHER Φ6	平垫Φ6	2
31-4	807092	CONNECTION PLATE	后牌照支架连接板	1
31-5	807072	RACK, REAR LICENSE	后牌照支架	1
31-6	315000	TAIL LIGHT ASSY	尾灯	1
31-6-1	315002	BULB 12V/21/5W	尾灯灯泡 12V/21/5W	1



32-1	307200-0160010	CDI UNIT	可控硅触发器CDI	1
32-2	303200-0160010	RECTIFICATION REGULATOR	整流调节器	1
32-3	s90625	BOLT M6×25	螺栓M6×25	1
32-4	q00600	SPRING WASHER 6	弹垫6	1
32-5	301200-0160010	START RELAY	起动继电器	1
32-5-1			保险片10A	1
32-6	302200-0160010	SHUTDOWN RELAY	切断继电器	1
32-7	306200-0160010	HIGH PRESSURE COIL ASSY	高压线圈组件	2
	306300-0150010	PROTECTING CAP	护帽	1
32-8	h00516	BOLT UNIT M5×16	十字大扁头螺栓M5×16	2
32-9	80606000-250ST-000000	REVERSE SWITCH	倒档开关	1
32-10	80607000-250ST-000000	NEUTRAL SWITCH	空档开关	1
32-11	304200-0150010	BATTERY ASSY	蓄电池组件	1
32-12	304301-0150010	PRESSURE BLOCK OF BATTERY	蓄电池压块	2



32-13	S90620	FLANGE BOLT M6×20	法兰面螺栓M6×20	2
32-14	304103-0150010	BUFTER PAD OF BATTERY PRESSURE BLOCK	蓄电池压块缓冲垫	1
32-15	304105-0150010	EARTH WIRE COMP	接地线组合	1
32-16	304105-0150010	BATTERY POSITIVE LEAD	蓄电池正极导线	1
32-17	316100-0150010	MAIN SWITCH LOCK	总开关锁	1
32-18	314600-0150010	NEUTRAL INDICATOR ASSY	空档指示灯组件	1
32-18-1	314701-0150010	BULB 12V3W	灯泡12V3W	1
32-19	314700-0150010	REVERSE INDICATOR ASSY	倒档指示灯组件	1
32-20	314a00-0150010	HIGH BEAM INDICATOR ASSY	远光指示灯组件	1
32-21	603114-0150010	CABLE CLIP 3	线夹3	2
32-22	931201-0150010	CABLE BAND	电缆箍带	6
32-23	931203-0150010	HANDLE BAR BAND	手把箍带	2
32-24	308400-0150010	CABLE	电缆	1
32-25	311000	FLASHER	闪光器	1

32-26 312000-0010010

HORN

喇叭

1